

## 2020 KTM/HUSQVARNA/WP – FORK & SHOCK TYPES

|                       | <b>HUSQVARNA – MX</b> | <b>HUSQVARNA – Enduro</b> | <b>KTM – MX</b>   | <b>KTM – Enduro</b> | <b>WP PRO – MX</b> | <b>WP PRO – Enduro</b>                  |
|-----------------------|-----------------------|---------------------------|-------------------|---------------------|--------------------|---|
| <b>FORK</b>           | XACT (air-sprung)     | XPLOR                     | XACT (air-sprung) | XPLOR               | XACT Pro           | XPLOR Pro                               |
| <b>SHOCK ABSORBER</b> | XACT (linkage)        | XACT (linkage)            | XACT (linkage)    | XPLOR (PDS)         | XACT Pro (linkage) | XPLOR Pro (both PDS & linkage versions) |